

Un-Pack



- Remove chair and adaptor box from all packaging. and discard / Re-cycle outer packaging waste safely.
- **2.** Check that your box contains:
 - 1x Chair
 - 1 x 12 v Adaptor
 - 1x Red/White RCA audio connection cable
 - 1x Red/White RCA to mini audio cable
 - 1x 3.5mm mini jack plug to RCA plug adaptor
 - 2 x RCA audio cable extenders



THATSYOUD





Games onsoles INPUT Red/White RCA audio connection cable (supplied) for extension if required. CHAIR **CONTROL PANEL** Red/White/Yellow RCA audio connection cable. (supplied with Games Console) GAME CONSOLE AUDIO INPUT 0(0) WHITE/RED YELLOW

